
SINGLE INJECTOR
32
12
INTERFACE UNIT BETWEEN ECU & PROPELLER**
30
FUEL & AIR
10
ECU UNIT
28
MOTOR
20
18
22
24
16
14
26

FIG.1.


58
56
FUEL & AIR
BATTERY/ POWER SUPPLY
+ -
INSTRUMENTATION /ECU
50
54
MOTOR
52
60

FIG.2.